

Honda VT 1300 models

Interstate/Stateline/Sabre

Ultimate Seats Installation

1. Remove original seats from your bike, first remove the bolt from the rear fender bracket (5mm allen key) then remove the side covers from both sides, remove the bolt from each side under the seat (5mm allen key) and store away, not needed.
2. Remove the seat by sliding it back and then up.
3. Install your new Ultimate seat by sliding the front locator bracket on the seat under the tank bracket and reinstall the original bolt in the rear fender bracket.

If you have purchased the Ultimate removable passenger backrest it is installed by lifting the Velcro flap and inserting the backrest into the receiving bracket built into the seat. Slide the post down until you feel the spring loaded plunger ball click into the machined groove in the backrest post.

Enjoy the ride again on your new Ultimate seat

**Questions ?
877-672-0288
des@ultimateseats.ca
www.ultimateseats.ca**