

Valk Standard & Tourer & Interstate
Ultimate KING Bigboy rider backrest

Installation instructions

Mounting hardware included

2 – bolts 6 mm x 20 mm w/washers

1 – hex key 4 mm

1. **Remove both rider and passenger seats from the bike.**
2. **Place your new Ultimate passenger seat on the rear fender and line up the bolt holes.**
3. **Place the King backrest bracket on the front passenger seat bracket and line up the bolt holes.**
4. **Screw in the two 6mm bolts supplied through the backrest and passenger seat brackets into the fender. (Fig 1)**
5. **Tighten the two front bolts and the rear bolt securely to complete the installation of your passenger seat and rider backrest.**
6. **Install the King Bigboy seat on the bike. (Fig 2)**



Fig 1



Fig 2

**Questions ?
877-672-0288
des@ultimateseats.ca
www.ultimateseats.ca**