

Can-Am Spyder GS/RS and ST – all models

Ultimate seat Installation - one pc seat

Install Kit for passenger backrest included

4 mm T handle allen key = 1

6 mm x 30 mm button head screw = 1 for passenger backrest

6 mm x 20 mm button head screws = 2 for sensor are in the seat base.

Tools needed

10 mm wrench x 2

13 mm wrench x 2

10 mm socket

13 mm socket

T30 torque

T40 torque

4 mm allen key

Small screw driver

Removal of Stock Seat

Remove the screw holding the rear body panel behind the seat (T30 torque)

Pull up on one side of the body panel to release the clips and then remove it.

With the seat in it's up position release the lift arm from the upper ball joint (small screw driver) and unplug the passenger sensor.

Now you can lift the seat up completely vertical and remove the 3 bolts from the rear mounting bracket (13 mm socket) and or T40 torque.

Lift off the seat and place it pan facing up on a table next to your new Ultimate seat.

Remove the mounting bracket and lift arm assembly bolt (10 mm wrench x 2) and long bushing, Install these onto your new Ultimate seat.

Remove the ball joint and install on the new seat (13 mm wrench x 2)

Remove the passenger sensor and install it in the new seat (T30 torque) and or 10 mm socket use the 2 new button head screws 6 mm x 20 mm that are in the new seat to install the sensor (4 mm allen key).

Remove the front latch pin and nut and install the pin into the new seat (10 mm wrench)

Note that the front latch pin is adjustable for depth. (13 mm wrench x 2)

Install the latch pin directly into the base pan threaded insert and adjust the length of the pin with the lock nuts, latch should be set to have a little up and down clearance.

Install the new seat on your Spyder.

With the lift arm removed latch the seat down and tighten only the rear bolt that you can see when the seat is down and latched, then lift the seat, tighten the other two bolts, install the lift arm and plug in the sensor.

Note - If you have the Ultimate removable passenger backrest install it before you replace the rear plastic body panel. Use the supplied 4 mm Allen key to screw in the 6 mm x 30 mm locking screw. Slide the backrest post into the seat receiving bracket and line up the threaded hole with the screw and tighten.

Enjoy the ride again on your Ultimate seats

Questions ?

877-672-0288

des@ultimateseats.ca

www.ultimateseats.ca