

# VALKYRIE ARMREST INSTALLATION

## Standard and Tourer

1. **Before you start, place a thick cloth over the fender below the area you will be working on for protection if you drop the parts.**
2. **Remove the passenger pad from the Sissy Bar, your stock pad will not work, must have the Ultimate passenger pad.**
3. **Remove the two outer bolts from the clamp and standing behind the Sissy Bar tilt the armrest so the clamp bracket can fit through the Sissy Bar and replace the two bolts.**
4. **Place the bracket just above or just below the 2 lower bolt pads, use these 2 pads to rest the mounting bolts against, this will also level the armrest. Only finger tighten the nuts and bolts until you adjust the height.**
5. **Have your passenger sit on the bike and make the height adjustment up or down**
6. **Install the passenger pad.**
7. **When dismantling you must first flip up the armrest .... Do not use them to push yourself up .... They are not intended to be used in this manner. Please make sure your passenger is told this. Damage to the hinge will occur if they are used incorrectly.**

Your new armrest has a quick release hinge pin so if you wish to remove the armrest and leave the mounting bracket attached to the backrest just pull the retaining sleeve and slide out the hinge pin.

**Questions ?**

**877-672-0288**

**des@ultimateseats.ca**

**www.ultimateseats.ca**