

# **STANDARD ARMREST INSTALLATION**

**Installs on most square and rectangular tube backrest sissy bar.  
(with standard clamp)**

- 1. Before you start, place a thick cloth over the fender below the area you will be working on for protection if you drop the parts.**
- 2. Remove the passenger pad from the sissybar.**
- 3. Remove the two outer bolts from the clamp and standing behind the Sissy Bar tilt the armrest so the clamp bracket can fit through the Sissy Bar and replace the two bolts.**
- 4. Take the entire armrest and standing behind the Sissy Bar tilt the armrest so the clamp bracket can fit through the Sissy Bar. Only finger tighten the nuts and bolts until you adjust the height.**
- 5. Have your passenger sit on the bike and make the height adjustment up or down**
- 6. Reinstall the passenger pad.**
- 7. When dismantling you must first flip up the armrest .... Do not use them to push yourself up .... They are not intended to be used in this manner. Please make sure your passenger is told this. Damage to the hinge will occur if they are used incorrectly.**

Your new armrest has a quick release hinge pin so if you wish to remove the armrest and leave the mounting bracket attached to the backrest just pull the retaining sleeve and slide out the hinge pin.

**Questions ?**  
**877-672-0288**  
**[des@ultimateseats.ca](mailto:des@ultimateseats.ca)**  
**[www.ultimateseats.ca](http://www.ultimateseats.ca)**