



[for the ultimate ride](#)

VTX 1300 R/S Bigboy seat

Included

1- Vinyl protector spacer

Seat installation

Install your new Ultimate Bigboy seat exactly like your stock seat using the stock bolts.

Install the rider backrest post into the receiving bracket in the Bigboy seat.

The receiving bracket inside the seat has a spring ball plunger that is factory preset and the backrest post has a machined V groove which the plunger clicks into when you slide the backrest post in.

Now you can install the Ultimate passenger seat onto your bike exactly the same as you would install the stock seat.

Place the included vinyl protector spacer between the front of the passenger seat and the rider backrest bracket to protect the 2 screw heads from rubbing against the seat.

Use the 2 stock bolts in each side of the passenger seat mounting bracket but do not use the vinyl strap or the 2 spacer washers from the strap bolt holes.

Reinstall the stock rear bolt into the seat rear bracket and into the fender.

Enjoy the ride again

Questions or comments
Toll free; 1-877-672 0288
Email; des@ultimateseats.ca
Web; www.ultimateseats.ca