



**for the ultimate ride**

## VTX 1800 C model

### Included

- 1- Round head screw – 1/4 “ – 20 x 1/2 ” long
- 1- Countersunk head screw – 1/4 “ – 20 x 1/2 “ long
- 1- Hex key 4 mm

### **seat installation**

Your new passenger seat has the connecting bracket already installed.  
Do not remove the connecting bracket from the passenger seat.

Attach the passenger seat connecting bracket to your Lowrider or Bigboy seat using the 2 supplied screws.  
The countersunk head screw in the countersunk slotted hole.

The rider and passenger seats should be flush together and then tighten the 2 screws.

Now you can install the Ultimate seat combination onto your bike exactly the same as you would install the stock seats.

Use the 2 stock bolts to mount the rider seat to the frame and the stock chrome nut to hold the passenger seat to the rear fender.

Enjoy the ride again

**Questions ?**  
**877-672-0288**  
**des@ultimateseats.ca**  
**www.ultimateseats.ca**