Ultimate Seats VTX 1800 N – NEO

SEAT INSTALLATION

Mounting hardware included;

One 6 mm x 20 mm bolt and washer

- 1. Remove the stock seats.
- 2. Remove the bolt from the center of the rear fender (10 mm socket)
- 3. Place the new passenger seat on the fender and line up the threaded hole in the fender with the passenger seat front bracket hole and install the new supplied bolt.
- 4. Replace the stock bolt into the rear seat bracket.
- 5. Install the rider seat exactly like stock using the 2 stock bolts on each side (6mm hex key)



