

**Electra Glide/Ultra/Road Glide
Road King/Street Glide
2014 and UP models
TOUR PACK RELOCATION PLATE KIT**

Installation Kit

Relocation plate = 1 pc

Screws ¼”-20 c/s flat head x 1” long = 4 pcs

Nuts ¼”-20 Nyloc nuts = 4 pcs

Washers ¼” = 4 pcs

Remove the seat first

1. Unplug the wiring connectors between the trunk and the bike.
2. Remove the four nuts under the trunk holding it to the frame, save for re-use.
3. Lift the trunk off the bike frame and place it on a protective surface.
4. Place the relocation plate onto the bike trunk frame in the most forward position and install the four supplied flat head screws with nuts and washers into the countersunk holes and tighten.
5. Use a 5/16” drill and drill through the 2 front holes in the plate through the trunk frame (this position gives you the one inch back trunk position) Pic #1.
6. Now loosen the 4 flat head screw nuts and slide the plate back to its rear most position and drill through again (this gives you the 2 inch back trunk position) Pic #2.
7. Position the plate now into the forward or back position and tighten the 4 flat head screw nuts.
8. Install the trunk now onto the relocation plate and use the original nuts to secure.
9. Plug in all of the wiring connectors.



Pic #1

Pic #2

Questions ??? call us on 1-877-672-0288

email des@ultimateseats.ca

Web site – www.ultimateseats.ca