

### Install kit

8m x 16m bolts = 2

Flange nuts ¼-20 = 2

OEM Heat Eliminator Plug

## Ultimate GL1800 Goldwing Tour (2018 and Newer)

### Installing Non Heated Seat on Bike with OEM Heat

#### TRUNK PASSENGER BACKREST –

1. Remove your stock passenger backrest; open the trunk and remove the 8 screws (pic 1) holding the stock passenger backrest on (Phillips head screwdriver). Close the trunk and lift backrest straight up slowly. Unplug OEM passenger backrest.
2. To reinstall OEM backrest – reverse of removal **but do not plug in the heat**.
3. To install the Ultimate passenger backrest align the bolt on each side of the backrest into the bolt holes in the trunk, from inside install the 2 supplied flange nuts and secure, do not overtighten.

#### MAIN SEAT:

1. Open saddlebags.
2. Remove side covers. Unplug heat plug found behind right side cover (pic 2).
3. Remove bolts holding front of seat to bike on both sides (6mm hex key) (store)
4. Pull straight up on front of seat. Then pull entire seat forward and up.
5. Install supplied heated seat eliminator where OEM heat was unplugged under right side cover.
6. To install your new seat - hold nose up and slide seat backward. Let front of seat down and install new supplied bolts that hold seat to bike on both sides.
7. Reinstall side covers and close saddlebags.

Pic 1



Pic 2



Questions? 1-877-672 0288

[sales@ultimateseats.com](mailto:sales@ultimateseats.com)

[www.ultimateseats.com](http://www.ultimateseats.com)

01/15/2020