

Ultimate GL1800 Goldwing 2001 - 2010

Installing Heated Seat on Bike without OEM Heat (Kit: 12V Heat Adapter)

1. Remove seat per supplied removal/installation instructions.
2. Install included 12v heat adapter in fuse box as shown (Red wire goes in top location). Run wire from adapter on inside of frame (pic 1). Note: Fuse box cover may need to be notched slightly to allow for proper closure of fuse box around wires.
3. Plug in your new seat to heat adapter. Finish installation per supplied removal/installation instructions

Pic 1



Questions?

877-672-0288

sales@ultimateseats.com

www.ultimateseats.com