

Can-Am Ryker

Ultimate seat install instructions – all Ryker models

The Can Am Max Mount is required to install the Ultimate seat

If you are riding a passenger you need to install passenger foot pegs from Can-Am

You must use the Loctite supplied on the bolt threads when installing the seat

Tools needed to install seat

- Socket 13 mm hex and extension
4 mm allen key

Install Kit Supplied

Blue Loctite thread locker

- 8 mm x 50 mm long hex head bolt and lock washer = 1 pc.
- Large 8 mm special washer = 1 pc.
- ¼” x ½” long button head screw and lock washer = 1 pc.

1. Remove the stock seats.
2. Place the Ultimate seat onto the Max Mount.
3. There is a locator on the bottom of the seats pan that fits into the Max Mount hole.
4. If you have the rear fender attachment on your max mount remove the 4 bolts to lower it down so you can install the 8 mm hex seat bolt.
5. Install the supplied 8 mm hex bolt and lock washer **with blue loctite** and large washer through the underside of the Max Mount into the base pan and tighten securely, do not over tighten.
6. If you ordered the Ultimate passenger backrest install it by sliding it into the rear receiving bracket.
7. Using a 4 mm allen key install the ¼” button head screw and lock washer **with blue loctite** from the underside of the seat.
8. If you ordered the Ultimate Driver backrest install it by sliding it into the receiving bracket.

Enjoy the ride again on your Ultimate seats.

Questions ?

877-672-0288

des@ultimateseats.com

www.ultimateseats.com