

Harley-Davidson® Softail® 2000 – 2005 Heritage – Deluxe – Fatboy - Standard

155 mm tire
Not wide tire models

Ultimate seats Installation

Install kit

Phillips pan head bolts 1/4" x 1/2" long with lock washers = 3 pcs

Round head allen bolts 1/4" x 3/4" long = 2 pcs

#1. Remove original seats from your bike.

#2. Your new Ultimate seats install exactly like your stock seats.

#3. All the mounting brackets are already installed on your new seats.

#4. Connect our passenger seat to the rider seat with the 2 new round head allen bolts (1/4" x 3/4")

#5. Use the 2 new supplied bolts to attach the rider seat to the bike frame, one on each side (**side mount**) (1/4" x 1/2") phillips pan head.

#6. Use the other new bolt for the passenger seat rear bracket in the fender (1/4" x 1/2") phillips pan head.

Enjoy the ride again

Questions ?

877-672-0288

des@ultimateseats.ca

www.ultimateseats.ca