

Can-Am Spyder RT – all models

Ultimate – Passenger backrest Installation

Tools needed to change passenger backrest

Torque wrench # T20 for the 2 top screws

Torque wrench # T30 for the 3 screws inside the trunk

Screw driver flat

4 mm Allan key for 2018 passenger backrest screws

1. Remove the stock passenger backrest pad by removing the 3 screws T30 inside the trunk (**be careful not to push too hard on the screws as the internal nuts will push out inside the backrest**) and then loosen the 2 small screws T20 on the top, just loosen these two enough so the backrest will slide out. Some models have two push pins instead of screws.
2. Remove the 4 plastic push pins on the back side of the backrest and separate the plastic liner from the backrest.
3. Now install the plastic liner piece onto the trunk from where it was removed, slide it under the two small screws. **The liner is not attached to your new Ultimate backrest.**
4. Now install the new Ultimate backrest and install the 3 screws inside the trunk to attach.
5. If you have a **2018 model** the attachment screws M6 x 20 **are include** in your new Ultimate backrest.

Enjoy the ride again on your Ultimate seats

Questions ?

877-672-0288

des@ultimateseats.ca

www.ultimateseats.ca