

ULTIMATE SEATS

Removable Rider Backrest Install

If you have the Ultimate removable rider backrest you install it by lifting the Velcro flap on the seat and sliding the backrest post into the backrest bracket inside the seat.

You will see a groove in the backrest post, there is a spring-loaded plunger inside the seat bracket that clicks into the groove.

When you fold the backrest forward and down for easy mount and dismount make sure the Velcro tab is folded forward and down so the adjustment bolt rests on it and not directly on the seat.

With the backrest in the upright riding position you can infinitely adjust the forward and back position by turning the adjustment bolt.

The backrest hinge should be adjusted so it tilts freely to the angle of your back but firm enough to stay in the set position.

Rider backrest pouch install

If you ordered the backrest with a storage pouch your new Ultimate rider backrest pouch is included in your backrest package.

There is a Velcro strip (soft side) attached to the chrome backrest post and a Velcro strip (hard side) attached to the back of the pouch.

First, attach the Velcro on the bottom of the pouch to the Velcro on the chrome post.

Make sure the pouch is not too low that it will get pinched between the adjustment bolt.

Now tuck the top of the pouch up under the rain flap on the backrest and attach it to the Velcro under the flap.

Questions ?
877 672 0288
des@ultimateseats.ca
www.ultimateseats.ca